

READ BEFORE USING

INSTALLATION INSTRUCTIONS FOR TWO-PIECE BLEED SCREW – PIPE THREAD STYLE ADAPTER

General Information

- •Threads in caliper must be clean and dry before installing the new bleed screw adapter.
- •Carefully remove any old sealant and brake fluid from the threads in the caliper body.
- •Do not contaminate the interior fluid passages in the caliper.
- •Use an inch-pound torque wrench only!

Installation

·Adapter fitting into caliper:

Torque to 125-150 in-lb (wrench size = 10mm)

•Bleed screw fitting:

Torque to 40 **in-lb** (wrench size = $\frac{1}{4}$ ")

- •Bleed screw should be installed into adapter fitting with clean, dry threads.
- •Do not use sealant or thread locking compound on bleed screw.

IMPORTANT: Read disclaimer of warranty included with the product.

- 4700 Calle Bolero • Camarillo, CA 93012 • Phone 805/388-1188 • www.wilwood.com

DS-1572 REV DATE 01-17-24



READ BEFORE USING

INSTALLATION INSTRUCTIONS FOR TWO-PIECE BLEED SCREW – PIPE THREAD STYLE ADAPTER

General Information

- •Threads in caliper must be clean and dry before installing the new bleed screw adapter.
- •Carefully remove any old sealant and brake fluid from the threads in the caliper body.
- Do not contaminate the interior fluid passages in the caliper.
- Use an inch-pound torque wrench only!

Installation

•Adapter fitting into caliper:

Torque to 125-150 in-lb (wrench size = 10mm)

•Bleed screw fitting:

Torque to 40 **in-lb** (wrench size = $\frac{1}{4}$ ")

- •Bleed screw should be installed into adapter fitting with clean, dry threads.
- •Do not use sealant or thread locking compound on bleed screw.

IMPORTANT: Read disclaimer of warranty included with the product.